

PFAFF

3568-1/22

-12/22

Service manual for control

Needle to center of folder is 650 mm Needle to center of the folder on the 3588 is 750 mm.

Max. sewing is 250 mm X and 220 mm Y.

Max. sewing on tge 3588 is 250 mm X and 250 mm Y

Notes on safety

- The machine must only be commissioned in full knowledge of the instruction manual and operated by persons with appropriate training.
- Before putting into service also read the safety notes and the instruction manual of the motor supplier.
- The machine must be used only for the purpose intended.
Use of the machine without the safety devices is not permitted.
Observe all the relevant safety regulations.
- When gauge parts are exchanged (e.g. needle, presser foot, needle plate, feed dog and bobbin) when threading, when the workplace is left, and during service work, the machine must be disconnected from the mains by switching off the main switch or disconnecting the mains plug.
- On mechanically operated clutch motors without start inhibitor it is necessary to wait until the motor has stopped.
- General servicing work must be carried out only by appropriately trained persons.
- Repairs, conversion and special maintenance work must only be carried out by technicians or persons with appropriate training.
- For service or repair work on pneumatic systems the machine must be disconnected from the compressed air supply system.
Exceptions to this are only adjustments and function checks made by appropriately trained technicians.
- Work on the electrical equipment must be carried out only by electricians or appropriately trained persons.
- Work on parts and systems under electric current is not permitted, except as specified in regulations EN 50110.
- Conversions or changes to the machine must be made only in adherence to all safety regulations.
- For repairs, only replacement parts approved by us must be used.
- Commissioning of the sewing head is prohibited until such time as the entire sewing unit is found to comply with EC regulations.

Meanings of the symbols:



Danger spot!

Items requiring special attention.



Danger of injury to operative

service staff.


Be sure to observe and adhere to these notes!

Contents:

	Page
Notes on safety	2
1 General information	4
1.1 The machine	4
1.2 The operating modes Automatic, Manual and Input	5
1.2.1 Automatic operating mode	5
1.2.2 Manual operating mode	5
1.2.3 Input operating mode	5
2 Control panels / Pictograms	6
2.1 Pictogram of the input control-panel	6
2.2 Input control-panel	7
2.3 The display	9
2.4 Folder control-panel	10
3 Input - brief description	12
3.1 Overview of the functions - Menu 1	13
3.2 Overview of the functions - Menus 1+2	14
3.3 Moving within the Menus	15
3.4 Menu 1	16
3.5 Menu 2	17
3.5.1 Program management	17
3.5.2 Seam pattern progr./correction	18
3.5.3 Counters	18
3.5.4 Switch functions	19
3.5.5 Times	21
3.5.6 Service	21
4 Error numbers - brief description	28
4.1 Sewing motor - error	28
4.2 Disk - error	28
4.3 Feed motor	29
5 Lock list	30
6 Overview of the switches / Proximity switches	40
7 Monitoring the jigs / - code	42
8 Important settings	44
8.1 Initial loading values after cold start	44
8.2 Synchronizer home setting	45
8.3 Feed speeds	45
Circuit diagrams	46

1 General information

1.1 The machine



Number	Name
1	input control-panel
2	carriage drive X-axis
3	carriage drive Y-axis
4	switch to sewing
5	jig feed
6	switch to feed
7	sewing station
8	folding station
9	folder control-panel

(see diagram previous page)

1.2 The operating modes Automatic, Manual and Input

When operating the machine a distinction must be made between the operating modes Automatic, Manual and Input . You can change from operating mode to operating mode by pressing the relevant keys on the control panels (The Input operating mode is only possible on the input control-panel).

When working within an operating mode, only certain functions are permissible. You may have to change to another operating mode in order to carry out other functions.

1.2.1 Automatic operating mode:

- | | |
|--|-------------------------------|
| - start | - presser foot up/down |
| - stop | - cycling (seam construction) |
| - home position X/Y carriages | - Error reset |
| - home position folder | - label feeder |
| - changing bobbins, stacker forward/back | - Program stations A and B |

1.2.2 Manual operating mode:

In addition to the automatic operating mode

- step by step (folder)
is also possible.

The start keys start only the sewing operation

1.2.3 Input operating mode:

See Input - brief description

2 Control panels / Pictograms

2.1 Pictogram of the input control-panel


To optimize its operation, the machine is equipped with two different control panels. One control panel (folder control-panel) is situated at the folding station and contains all of the keys which are necessary for the normal sewing operations. A second control panel (input control-panel) is situated on the front of the machine and is mainly used for setting up the machine.

A second, separate control panel is necessary (program control-panel) for programming. The description of this control panel can be found in a separate booklet for programming.


Following is a list of pictograms of the individual control panels and their uses.


2.2 Input control-panel

1 Statusline



2 Buttons







2.3 The display

The display consists of a two line LCD (Liquid Crystal Display). In the first line the various data-status indicators are displayed, such as: program number, jig code, stitch length, maximum speed, actual speed and unit counter. This status line remains displayed. In the second line the various texts are displayed, such as for example error messages and the input cursor etc. This line has a text number which allows the clear classification of the display texts in the various languages.


display diagram




2.4 Folder control-panel




on/off switch (under the control panel)




emergency stop




control on




manual mode




automatic mode




start




stop




step-by-step folder




home position folder




don't sew




error reset





label



program station A



program station B



Input - brief description

In the input mode a distinction must be made between directly selectable functions and functions which can only be selected via the menu. Directly selectable functions have their own keys and can be selected by pressing these keys.

The directly selectable functions are:

- program station A
- program station B
- select program numbers (station programming)
- automatic program change
- alter stitch length
- reset bobbin-thread stitch-counter

Other functions can be selected via the menus (see overview of the menu functions). There are two menu levels.

1. Menu level 1 (1st menu)

The frequently required functions are stored in this menu level. Sub functions cannot be selected from here (except entry into the 2nd menu level).

2. Menu level 2 (2nd menu)

The less frequently required functions are stored in this menu level. These functions are subdivided into main functions and sub functions.

Select function or scroll (Basic condition 1st menu)

3.1 Overview of the functions - Menu 1

CHOOSE FUNCTION OR SCROLL (BASIC CONDITION 1ST MENU)

- 1 - PIECE COUNTER
- 2 - BOBBIN PRESELECT
- 3 - TIME FOR FEED ROLLER
- 4 - MAXIMUM SPEED
- 5 - REDUCED SPEED
- 6 - ZIGZAG DELAY ON
- 7 - ZIGZAG DELAY OFF
- 8 - INTERMEDIATE STOP
- 9 - PULLER
- 0 - PLAIN FABRIC

MENU 2 (only by pressing "+","-")


3.2 Overview of the functions - Menus 1+2

- | | |
|---|--|
| CHOOSE FUNCTION OR SCROLL (BASIC CONDITION 1ST MENU) | |
| 1- PIECE COUNTER
2- BOBBIN PRESELECT
3- TIME FOR FEED ROLLER
4- MAXIMUM SPEED
5- REDUCED SPEED
6- ZIGZAG DELAY ON
7- ZIGZAG DELAY OFF
8- INTERMEDIATE STOP
9- PULLER
0- PLAIN FABRIC
2. MENU (ONLY BY PRESSING "+" , "-") | |
| 2. MENU | |
| 1 PROGRAM MANAGEMENT <ul style="list-style-type: none"> - 1- PROGRAM DIRECTORY <ul style="list-style-type: none"> - 1- MEMORY DIRECTORY - 2- DISK DIRECTORY - 2- READ PROGRAM FROM DISK <ul style="list-style-type: none"> - 1- READ ONE PROGRAM FROM DISK - 2- READ ALL PROGRAMS FROM DISK - 3- DELETE PROGRAM <ul style="list-style-type: none"> - 1- DELETE ONE PROGRAM (MEMORY) - 2- DELETE ALL PROGRAMS (MEMORY) - 3- DELETE ONE PROGRAM (DISK) - 4- DELETE ALL PROGRAMS (DISK) - 4- WRITE PROGRAM ON DISK <ul style="list-style-type: none"> - 1- WRITE ONE PROGRAM ON DISK - 2- WRITE ALL PROGRAMS ON DISK - 5- STATISTICAL PROGRAM DATA - 6- FORMATTING DISK (DELETE) - 7- DATA TRANSFER WITH PC - 2- SEAM PATTERN PROGR. / CORRECTION - 3- COUNTERS <ul style="list-style-type: none"> - 1- REM. STITCH COUNT, NDL.THR. MON. - 2- REM. STITCH COUNT, BOBBIN THR.MON - 3- MONITORING STICHES, NDL.THR.MON. - 4- AUTOMATIC STITCH REVERSE - 5- SLOW STARTING STITCHES - 6- CARRIAGE START (NIF) - 4- SWITCH FUNCTIONS <ul style="list-style-type: none"> - 1- THREAD MONITOR FUNCTIONS <ul style="list-style-type: none"> - 1- THREAD MONITOR - 2- BOBBIN MONITIR - 3- BOBBIN SENSOR - 2- LANGUAGES <ul style="list-style-type: none"> - 1- GERMAN - 2- ENGLISH - 3- FRENCH - 4- SPANISH - 5- ITALIAN - 3- AIRBLAST SELECTION <ul style="list-style-type: none"> - 1- NEEDLE COOLING, FEED FORWARD - 2- NEEDLE COOLING, STACKER - 3- AUX. FEED, FEED FORWARD - 4- AUX. FEED, STACKER - 5- AUX. FEED, SEWING - 4- OTHER FUNCTIONS <ul style="list-style-type: none"> - 1- THREAD PULLER - 2- BOBBIN CHANGE FROM TOP - 3- JIG MONITOR - 4- LABEL FEEDER - 5- LABEL ALTERNATELY - 6- CARRIAGE MOVEMENT - 7- SLOW TRIGGERING - 8- BAS. FRONTPOS. POCKET-PLATE - 5- TIMES <ul style="list-style-type: none"> - 1- TIME FOR STACKER AIRBLAST - 2- TIME FOR FABRIC FEED COVER - 3- TIME FOR PULLER DOWN - 4- TIME AFTER TABLE UP - 5- TIME FOR EDGE FOLDERS BACK - 6- TIME FOR FEED FORWARD - 7- TIME FOR THREAD PULLER - 6- SERVICE <ul style="list-style-type: none"> - 1- SEWING MOTOR FUNCTIONS <ul style="list-style-type: none"> - 1- SEWING MOTOR RUNNING - 2- TRIMMER SPEED SELECTION - 3- THREAD TRIMMING SEQUENCE - 2- STEPPING MOTORS <ul style="list-style-type: none"> - 1- STEPPING MOTOR X-AXIS - 2- STEPPING MOTOR Y-AXIS - 3- DISPLAY INPUTS - 4- SET / RESET OUTPUTS - 5- SET ZERO POINT - 6- SOFTWARE DATE - 7- COLD START | |

3.3 Moving within the menus


With the help of the keys "+" and "-" you can display all of the main functions and their function numbers. If a valid function number is selected, the input function for this function number can begin. Similarly, the currently displayed function can be selected with the "Enter" key. Main functions can be divided into several sub functions and these into still more sub functions. All sub functions can be displayed and selected in the same way as main functions. A main function or sub function that has already been selected can be stopped with the "ESC" key. Thus the superordinate program is returned to.

Diagram



E.G. Bobbin-thread-monitor selection from the home position

Press keys:



3.4 Menu 1

3.4.1 Piece counter

The piece counter informs as to the current daily production. The highest number which can be displayed is 65565. When this amount is surpassed, the counter recommences at 0. The current amount in the display can be zeroed by pressing the "CLEAR" key.

3.4.2 Bobbin preselect

The bobbin preselect allows the operator to stop the machine at the end of a seam pattern to change bobbins if the machine exceeds a given amount of stitches. When this function is selected, the current setting is displayed as a number of stitches. A new setting can then be selected.

3.4.3 Time for feed roller

This function selects the duration of the feed pull operation.

3.4.4 Maximum speed

This function sets the maximum speed level.

3.4.5 Reduced speed

This function sets the reduced speed level.

3.4.6 Zigzag delay on

This function allows the operator to delay the zigzag-on function. The input is made as a number of stitches for which the switching on of the valve is to be delayed.

3.4.7 Zigzag delay off

As for 3.4.6 but for zigzag-off.

3.4.8 Intermediate stop

This function allows the operator to interrupt the folding operation manually in order to carry out any corrections or applications etc. which may arise. This function can be switched on and off.

3.4.9 Puller

The Puller serves as a stacking aid for short pieces. If a puller is installed, it can be switched on and off with this function.

3.4.10 Plain fabric

If the plain fabric function is switched off, the pocket plate is disengaged by activating the foot switch and the folding process can be started by pressing the double start keys.

If the plain fabric function is on, the folding procedure is started directly by pressing the double start keys.

3.4.11 Menu 2

This function opens the 2nd menu level.

3.5 Menu 2

3.5.1 Program management

All of the sub functions which have to do with the organisation of sewing programs are listed under the main function “program management”.

3.5.1.1 Program directory

This sub function calls up further sub functions in order to list the contents of the machine’s memory or a disk.

3.5.1.1.1 Memory directory

This sub function lists the contents of the machine’s memory.

3.5.1.1.2 Disk directory

This sub function lists the contents of a disk.

3.5.1.2 Read program from disk

This sub function allows further sub functions to be called up in order to load sewing programs from a disk into the machine’s memory.

3.5.1.2.1 Read one program from disk

A selected program is copied into the machine’s memory. Existing programs can be deleted if desired.

3.5.1.2.2 Read all programs from disk

All programs are copied from a disk into the machine’s memory. Existing programs can be deleted if desired.

3.5.1.3 Delete program

This sub function, calls up further sub functions in order to delete programs.

3.5.1.3.1 Delete one program (memory)

This sub function deletes one selected program in the machine’s memory.

3.5.1.3.2 Delete all programs (memory)

This sub function deletes all of the functions in the memory.

3.5.1.3.3 Delete one program (disk)

This sub function erases one program on disk.

3.5.1.3.4 Delete all programs (disk)

This sub function erases all of the programs on the disk (the disk is reformatted)

3.5.1.4 Write program on disk

This sub function calls up further sub functions in order to copy sewing programs from the machine memory onto disk.

3.5.1.4.1 Write one program on disk

A selected program is copied from the machine memory onto disk. Existing programs can be erased if desired.

3.5.1.4.2 Write all programs on disk

All programs are copied from the machine memory onto disk. Existing programs can be erased if desired.

3.5.1.5 Statistical program-data

The following statistical program-data are displayed:

- Number of stitches and program size in bytes
- Stitch length and obstacles
- Template code

3.5.1.6 Formatting disk (delete)

This sub function formats disks. All the data on the disk are thus erased.

3.5.1.7 Data transfer with PC

This sub function prepares the machine to communicate directly with a PC (personal computer) and the software SYS3000. For detailed information see the description System 3000.

3.5.2 Seam pattern progr./correction

This main function allows programs to be written or modified on the machine itself. A separate control panel is necessary. The programming is described in more detail in a separate booklet.

3.5.3 Counters

The main function "counters" allows the operator to program various function counters to suit his requirements. The various function counters are divided into sub functions.

3.5.3.1 Rem. stitch count, ndl.thr. mon.

The number of stitches can be entered for which the thread monitor is not considered when sewing on.

3.5.3.2 Rem. stitch count, bobbin thr. mon

The number of stitches can be entered for which the bobbin monitor is not considered when sewing on.

3.5.3.3 Monitoring stitches, ndl.thr.mon.

The number of stitches which must be completed before a needle-thread disturbance is recognized can be entered. A smaller number of stitches means a higher sensitivity level of the thread monitor and a larger number of stitches means a less sensitive needle-thread monitor.

3.5.3.4 Automatic stitch-reverse

The number of stitches which are to be reversed automatically in case of a needle-thread disturbance can be entered.

3.5.3.5 Slow starting stitches

The number of stitches which are to be carried out at a lower speed can be entered.

3.5.3.6 Carriage start (NIF)

The exact point in time of the carriage start (stepping motors) can be entered. This input is made in degrees after the needle t.d.c.

3.5.4 Switch functions

The main function "switch functions" switches a selection of machine functions on and off. The machine must of course be equipped with the required options.

3.5.4.1 Thread-monitor functions

Further sub functions are listed under this sub function in order to select the thread monitors.

3.5.4.1.1 Thread monitor

The thread monitor can be turned on and off.

3.5.4.1.2 Bobbin monitor

The bobbin monitor can be turned on and off. Here it is immaterial if the bobbin-thread monitor is reached via the stitch counting or the sensor.

3.5.4.1.3 Bobbin sensor

There are two types of bobbin monitor to choose from:

1. The bobbin monitor with stitch counter (Bobbin sensor off).
2. The bobbin monitor with sensor (Bobbin sensor on).

3.5.4.2 Languages

There are various languages which can be selected at any time by the operator. The languages available can be seen in the overview of the menu functions.

3.5.4.3 Airblastselection

There are a number of compressed air options to choose from which can be switched on and off.

3.5.4.3.1 Needle cooling, feed forward

3.5.4.3.2 Needle cooling, stacker

3.5.4.3.3 Aux. feed, feed forward

3.5.4.3.4 Aux. feed, stacker

3.5.4.3.5 Aux. feed, sewing

3.5.4.4 Other functions

This sub function contains a list of all of the sub functions which cannot be attributed to any of the above mentioned functions.

3.5.4.4.1 Thread puller

The thread puller option can be switched on or off.

3.5.4.4.2 Bobbin change from top

The bobbin change from top option can be switched on or off.

3.5.4.4.3 Jig monitor

The jig-monitor option can be switched on and off.

3.5.4.4.4 Label feeder

The label feeder option can be switched on and off.

3.5.4.4.5 Label alternately

When working within the label feeder mode, the process can be altered so that only every second pocket receives a label. This requires that the alternating label feeder mode be switched on.

3.5.4.4.6 Carriage movement

The type of carriage movement (stepping motors) can be set.

1. Carriage movement intermittent (continuous off)
2. Carriage movement continuous (continuous on)

3.5.4.4.7 Slow triggering

The movement speed from the machine's zero point to the sewing position can be set at slow or normal.

3.5.4.4.8 Bas. frontpos. pocket-plate

Either the basic front position can be selected for the pocket-plate (basic front position pocket-plate on), or the basic back position (basic position pocket-plate off).

3.5.5 Times

The sub functions of the times which the operator can alter are listed under the main function "times".

3.5.5.1 Time for stacker airblast

The blast duration for the blast nozzles can be entered at the stacker.

3.5.5.2 Time for fabric feed cover

The time from folder on to folder off can be entered.

3.5.5.3 Time for puller down

The delay time between feed reverse (feed no longer forward) and puller off can be entered.

3.5.5.4 Time after table up

The duration of the delay of the folding process after switching to table on and the signal table at top being displayed.

3.5.5.5 Time for edge folders back

The duration of the delay between withdrawal of the slide and folder on can be entered.

3.5.5.6 Time for feed forward

The delay time between the pocket plate no longer being at the front and feed forward can be entered.

3.5.5.7 Time for thread puller

The switching time of the thread puller can be entered.

3.5.6 Service

Further sub functions are available under the main function service for testing the control and the machine. The service functions can be selected at any time.

3.5.6.1 Sewing motor functions

Further sub functions for testing the sewing motor are available under this sub function.

Attention:

Care must be taken to ensure that the needle can enter freely into the needle hole while this function is being carried out.

No locks are considered!

3.5.6.1.1 Sewing motor running

This function starts the sewing motor and stops it again. The speed can be preset and also altered while the motor is turning over.

3.5.6.1.2 Trimmer speed selection

This function presets the trimmer speed

3.5.6.1.3 Thread trimming sequence

The thread-trimmer cycle is triggered off by this function.

3.5.6.2 Stepping motors

Further sub functions for testing the stepping motors are available under this sub function. The stepping motors are driven with a slow, constant frequency.

Attention:

Care must be taken to ensure that the movement of the carriage is not obstructed while this function is being carried out.

No locks are considered!

3.5.6.2.1 Stepping motor X-axis

The step-by-step motor of the X-axis can be driven. The motor rotates clockwise when the "+" key is pressed (seen on the motor flange).

3.5.6.2.2 Stepping motor Y-axis

The step-by-step motor of the Y-axis can be driven. The motor rotates clockwise when the "+" key is pressed (seen on the motor flange).

3.5.6.3 Display of inputs

The states of the inputs of the individual circuit boards are displayed from left to right.
The order corresponds to the LED layout on the terminal strips of the back panels.

The displays mean:

- 1=LED bright (low-signal)
- 0=LED dark (high-signal)

Terminal	Input card	Input	Operated When>>>>
1	A26	E 1	>Presser foot is up.
2	"	IN 1	Programmable input 1
3	"	E 28.5	>Template change/over for transfer is off (right).
4	"	E 20.2	>Pocket plate is forward.
5	"	E 20.1	>Pocket plate is back.
6	"	E 114	Manual push button for PROGRAM A.
7	"	E 23.2	>Folding unit is down.
8	"	E 23.1	>Folding unit is up.
9	"	KIPP	Signal that sewing head lift for bobbin change has been installed.
10	"	OPTINP	Options entr. card entered.
11	"	E 26.2	>Template is up.
12	"	E 26.1	>Template is down.
13	"	E 27.2	>Template transfer is back (folding station position).
14	"	E 27.1	>Template transfer is forward (sewing position).
15	"	E 28.1	>Template change/over for sewing is on.
16	"	E 28.4	>Template change/over for transfer is on.
17	"	E 28.2	>Template change/over for sewing is off.
18	"	E 37	>Sinking table is up.
19	"	E 31.2	>Template transfer moves to slow speed position, (folding station end).
20	"	E 31.1	>Template transfer moves to slow speed position, (sewing end.)
21	"	E 107	Foot operated switch for pocket plate down (stripe mode).
22	"	E 108A	Push button for starting folding cycle.
23	"	E 108B	Push button for starting folding cycle.
24	"	E 28.3	>Template change/over for transfer is off (left).

Terminal	Input card	Input	Operated When>>>
1	A 27	E 41.2	>Puller is down.
2	"	E 41.1	>Puller is up.
3	"	E 42	>Stacker clamping bar is forward.
4	"	E 50.1	>Sewing head is down.
5	"	E 51.1	>X stepper motor is in home position.
6	"	E 50.2	>Sewing head is up.
7	"	E 51.3	>Limit sensor for X stepper motor.
8	"	E 52.1	>Y stepper motor is in home position.
9	"	E 104	Manual push button for AUTOMATIC.
10	"	E 106	Manual push button for ERROR RESET.
11	"	E 111	Manual push button for STEPPING machine through cycle.
12	"	E 112	Manual push button for folding unit go to HOME position.
13	"	E 98	>Safety bar is out.
14	"	E 99	>Cover for stepper drive area is closed.
15	"	E 115	Manual push button for PROGRAM B.
16	"	SPGTST	>Signal that +12 volt ext is OK.
17	"	E 101	Manual push button for START.
18	"	E 113	Manual push button for NO SEW.
19	"	E 102	Manual push button for STOP.
20	"	E 9	>Thread monitor is activated. (check spring)
21	"	E 103	Manual push button for MANUAL.
22	"	SMOKPR	>Stepper motor drives OK, air pressure OK.
23	"	E 29.1	>Folding unit in front position.
24	"	E 29.2	>Folding unit in back position.

Terminal	Input card	Input	Operated When>>>>
1	A 28	JIGCODE	JIGCODE BIT 0 (operated by magnet in plate).
2	"	"	JIGCODE BIT 1 (operated by magnet in plate).
3	"	"	JIGCODE BIT 2 (operated by magnet in plate).
4	"	"	JIGCODE BIT 3 (operated by magnet in plate).
5	"	"	JIGCODE BIT 4 (operated by magnet in plate).
6	"	"	JIGCODE BIT 5 (operated by magnet in plate).
7	"	"	JIGCODE BIT 6 (operated by magnet in plate).
8	"	"	JIGCODE BIT 7 (operated by magnet in plate).
9	"		Free.
10	"		Free.
11	"		Free.
12	"		Free.
13	"		Free.
14	"		Free.
15	"		Free.
16	"		Free.
17	"	BOBERR	Bobbin thread disturbance.
18	"	ET	Label feeder installed.
19	"	E 120	Manual push button for loading a label.
20	"	ETRDY	Manual push button label finished.
21	"	ETINKL	>Label feeder is in brackets.
22	"	ETERR	>Label feeder error.
23	"	JIGCODE	Jig monitor is installed.
24	"		Free

3.5.6.4 Set / reset outputs

After selecting the code number, the appropriate output can be set with the digit "1" or reset with the digit "0".

If an output cannot be set, there will be an error message. If there is an "S" next to the code number in the table, the output can only/also be actuated via a special function (see end of table).

Terminal	Output card	Output	Function	Code no.
1	A22	Y 1	Presser foot off, thread nipper on.	8
2	"	K 2	thread trimmer on.	9
3	"	Y 3	compressed air, needle cooler on.	10
4	"	Y 20.2	pocket plate forward.	11
5	"	Y20.1	pocket plate back.	12
6	"	Y 70	Positioning clamp pressure on	13
7	"	ETSRART	start label feeder	14
8	"	K 22	positioning magnet folder on	15
9	"	Y 23.2	folder and table down.	16
10	"	Y 23.1	folder and table up.	17
11	"	Y 24.2	edge folders forward	18
12	"	Y 24.1	edge folders backward	19
13	"	H 120	label feeder lamp	20
14	"	Y 26.2	template up.	21
15	"	Y 26.2	template down.	22
16	"	H 115	indicator light program B on.	23
17	"	H 114	indicator light program A on.	0
18	"	Y 28.1	template change over for sewing on.	1
19	"	Y 28.2	template change over for transfer on.	2
20	"	Y 29.1	folding unit forward.	3
21	"	Y 5	thread puller on.	4 (S)
22	"	Y 31	pocket plate number 1 up.	
23	"	Y 45	compressed air material aid on	
24	"	Y 29.2	folding unit back.	

Terminal	Output card	Output	Function	Code no.
1	A 23	Y 40	Vacuum stacker roller on	32
2	"	Y 41	Puller down	33
3	"	Y 42	Stacker forward	34
4	"	Y 43	Compressed air stacker on	35
5	"	K 44	Stacker roller on	36
6	"	Y 50.1	Sewing head down.	37
7	"	Y 50.2	Sewing head up.	38
8	"	SPWOUT	Bobbin change.	39
9	"	OUT 1	Programmable output 1	40
10	"	OUT 2	Programmable output 2	41
11	"	Y 10	Zig Zag on. (programmable out 3).	42
12	"	Y 11	Extra tension control on.	43
13	"	REF	Reference output for NIF. (NIS)	44
14	"	BOBRES	Reset for bobbin monitor.	45
15	"		free	46
16	"		free	47
17	"	H 103	Indicator light (manual) on.	24
18	"	H 104	Indicator light (automatic) on.	25
19	"	Y 6	Hook lubrication on.	26
20	"	H 106	indicator light (error reset) on.	27
21	"	STR	Template transfer motor moves right.	28 (S)
22	"	STL	Template transfer motor moves left.	29 (S)
23	"	S 1	Template transfer motor frequency 1.	30 (S)
24	"	S 2	Template transfer motor frequency 2.	31 (S)
Special orders				
21	A 22	Y 5	Thread puller function	48
		Y 27.1	Template transfer forward (to sewing position).	49
		Y 27.2	Template transfer backward. (to folding position).	50

3.5.6.5 Set zero points

Before using the machine for the first time, the X-,Y carriage must be set with the help of the zero-point jig. The setting is not effected by moving the proximity switches, but rather by saving a correction value to the machine's zero point (proximity switches).

The adjustment is controlled by the menu and is carried out as follows:

1. call up the menu-point adjust zero-point.
2. press home-position key.
3. Mount the zero-point jig and confirm the command with the "ENTER" key.
4. find the zero point by moving the X-,Y carriage in the various directions with keys "4","6","2","8". Press "ENTER".

The correction values are in the machine's memory under CPU and will not be erased by a cold start.

Attention:

The zero point must be set again if the CPU or a zeroing proximity switch of the X-,Y carriage is changed.

3.5.6.6 Software data

The date on which the control software is written (CPU) can be displayed.

3.5.6.7 Cold start

A cold start can be initiated by calling up this function. A cold start sets all of the settings back to their initial values. All programs are erased.

Error numbers - brief description

In the machine, modules with their own controls are used. Some of these controls have their own error messages which are displayed on the machine's control panel.

4.1 Sewing motor

If there is an error in the sewing motor during an operation, the operation is stopped and an error message appears. The error message is produced by the motor's automatic control system M-MR-3. The message "error sew motor ()" appears in the display. The number/letter in brackets is an aid to correcting the error.

Number:	Comment
1	timeout command sequence
2	communication error
3	overheat motor
4	wrong command
5	overheat final stage (LD 17)
6	overcurrent
7	volt surge intermediate circuit
8	error 15V
9	motor won't turnover - no synchronizer pulse - no electricity LD 17 - no armature-status pulse
A	synchronizer pulses confused

4.2 Disk error

If there is an error at the disk station during an operation, the operation is stopped and an error message appears. The error message is produced by the disk station.

Some errors will be displayed as text and others as numbers. In the latter case the message "disk error (No.)" will appear in the control-panel display. The number in brackets is an aid to correcting the error.

Number:	Comment
1	transmission error serial interface
2	wrong command
3	syntax error
4	invalid character in data field
5	
6	disk unnamed
7	sector not found
8	error in file-link table
9	sector has wrong audit total
10	file not found
11	type error
12	disk/file write protected
13	disk full
14	disk directory full
15	write over existing file (warning)
16	drive not ready/no drive selected
17	read-error disk
18	wrong disk format
19	format error

4.3 Feed motor

In some cases there can be a disturbance during an operation with the feed motor which is not recognized by the control.

In such a case, the frequency regulator may display an error message in the form of a blinking LED.

The following is a list of the possible blink-signals.

H1(yellow) blinks	status/reason	Solution/comment
_____ _____ 1 x	computer error	turn mains off and on again (reset)
_____ _____ 2 x	mains off, under voltage	blinks until UZK < 65V reset automatic
_____ _____ 3 x	over-voltage switch-off $I > 180\% I_N$, short circuit	check drive / motor cable
_____ _____ 4 x	over voltage or motor per generator	check mains check drive
_____ _____ 5 x	Ixt Abschaltung Motor	motor overloaded check drive
_____ _____ 6 x	Ixt switch-off converter	converter overloaded check drive
_____ _____ 7 x	overheat motor	check bridge X5/10-11 motor overloaded
_____ _____ 8 x	overheat converter	converter overloaded converter overloaded
_____ _ 9 x	error in EEPROM	turn mains off and on again (reset)

Further details about the frequency converter can be found in its own instruction manual.

5 Lock list

The lock helps localize disturbances in the machine which are caused by wrongly adjusted or defective transmitter or servo components. There are two basic types of errors:

- feedback errors
- locking errors

Feedback errors occur when a function (output command) is given by the control and the expected feedback from the transmitter (input device) is not received.

Locking errors occur when a function should be actuated but may not be actuated due to the current machine status. (therefore damage to the machine might occur if the function is actuated).

Due to the error messages in the display, the signals in the lock list by the corresponding functions and the corresponding columns must be controlled.

In order to simplify the allocation of functions and columns, the text numbers in the lock list are repeated in columns lock or feedback.

The LED states mentioned are target values.

LOCK LIST FOR 3568-12/22

Function	Position of the machine	Input	Card/ Wire #	LED	Output	LED	Feedback	LED
	"...#009" press dual start switches	E108A E108B	A26/22 A26/23	on on				
Err: S M Amplifier or Comprd: air	"...#024"						A27/22	on
Err: Power Supply 12 V	"...#025"						A27/16	on check middle screws on X 16
Change at input (KIPP)	"...#026" top side bobbin change installed						A26/9	on
Feed	"...#057" Needle at top dead center Template change/over for sewing on Template change/over for transfer (left) off Template change/over for transfer (right) off Template down Puller up Sewing head down Presser foot up E28.1 E28.3 E28.5 E26.1 E41.1 E50.1 E 1	A26/15 A26/24 A26/3 A26/12 A27/2 A27/4 A26./1	on off off on on on on				
Sew	"...#058" Template change/over for sewing on Template change/over for transfer (left) off Template change/over for transfer (right) off Template down Puller up Sewing head down Presser foot down	E28.1 E28.3 E28.5 E26.1 E41.1 E50.1 E 1	A26/15 A26/24 A26/3 A26/12 A27/2 A27/4 A26/1	on off off on on on off	A22/10	on	E23.1	A26/2 on
	"...#059" Check to see if motor controller board A4 has an E-PROM # 79-0011-0091/001 If it does change to E-PROM # 79-0011-0091/003 and also change D21 if it does not have the number D21/0043/003 on the white label.							
Go to machine zero point	"...#060" (CHECK IF) Template change/over for transfer is on and E28.4 Template change/over for sewing is off E28.2 (OTHERWISE CHECK) Needle is at top dead center Template change/over for sewing on E28.1 Template change/over for transfer (left) off E28.3 Template change/over for transfer (right) off E28.5 (AND) Template down E26.1 Puller up E41.1 Sewing head down E50.1 Presser foot up E 1		A26/16 A26/17	off on				

LOCK LIST FOR 3568-12/22

Function	Position of machine	Input Card Wire #	LED	Output LED	Feedback LED
Cycling (manually moves template forward or backward for aligning)	"...#064" Needle is out of template Template change/over for sewing on Template change/over for transfer (left) off E28.3 A26/24 off Template change/over for transfer (right) off E28.5 A26/3 off Template down E26.1 A26/12 on Puller up E41.1 A27/2 on Sewing head down E50.1 A27/4 on Presser foot up E 1 A26/1 off				
Y 1 on Presser foot down Thread clamp open			A22/1 on	"...#100" E 1 A26/1 on	
Y1 off Presser foot up Thread clamp closed	"...#102" During seam pattern program correction Needle out of material...		A22/1 off	"...#101" E 1 A26/1 on	
K 2 on Thread trimmer on			A22/2 on		
K2 off Thread trimmer off			A22/2 off		
Y 3 on Compressed-air Needle cooling on			A22/3 on		
Y3 off Compressed-air Needle cooling off			A22/3 off		
Y 5 on Thread puller on			A22/21 on		
Y 5 off Thread puller off			A22/21 off		
Y 6 on Lubrication on			A23/19 on		
Y 6 off Lubrication off			A23/19 off		
Y 10 on Zigzag on			A23/11 on		
Y 10 off Zigzag off			A23/11 off		
Y 11 on Extra thread tension on			A23/12 on		
Y 11 off Extra thread tension off			A23/12 off		
Y 20.1 on Pocket plate back	"...#104" Folding unit up Opposite solenoid Y 20.2 de-energized if	E23.1 A26/8 on A22/4 is off	A22/5 on	"...#103" E20.1 A26/5 on E20.2 A26/4 off	

LOCK LIST FOR 3568-12/22

Function	Position of machine	Input	Card	LED Wire #	Output	LED	Feedback	LED
Y 20.2 on Pocket plate forward	"...#106" Folding unit up Opposite solenoid Y 20.1 de-energized if (IF) Template has changed over for sewing (OTHERWISE CHECK) Template transfer forward position	E23.1 E28.1 E28.3 E28.5 E27.1	A26/8 A22/5 is A26/15 A26/24 A26/3 A26/14	on off on off off off	A22/4	on	"...#105" E20.1 A26/5 off E20.2 A26/4 on	
K 22 on Positioning magnet folder on					A22/8	on		
K 22 off Positioning magnet folder off					A22/8	off		
Y 23.1 on Folder and table up	"...#108" Opposite solenoid Y 23.2 de-energized if		A22/9 is	off	A22/10	on	"...#107" E23.1 A26/8 on E23.2 A26/7 off E 37 A26/18 on	
Y 23.2 on Folder and table down	"...#110" Template transfer at forward position Opposite solenoid Y 23.1 de-energized if Folding unit not at back position Pocket plate down Y 31 solenoid de-energized if	E27.1 E29.2 A22/22	A26/14 A22/10 is A27/24 is	off off off off	A22/9	on	"...#109" E23.1 A26/8 off E23.2 A26/7 on E 37 A26/18 off	
Y 24.1 on Folder-feed back	"...#111" Opposite solenoid Y 24.2 de-energized if		A22/11 is	off	A22/10	on		
Y 24.2 on Folder-feed forward	"...#113" Opposite solenoid Y 24.1 de-energized if		A22/12 is	off	A22/11	on	"...#112" E 37 A26/18 on	
Y 26.1 on Template down	"...#115" Template transfer at front position (OR) Template transfer at back position Opposite solenoid Y 26.2 de-energized if IF Template transfer is in forward position Sewing head down IF Template transfer is in back position and Template change/over for transfer on Pocket plate down Y 31 de-energized if	E27.1 E27.2 E27.1 E50.1 E27.1 E28.2 E28.4 A22/22	A26/14 A26/13 A22/14 is A26/14 A27/4 A26/14 A26/17 A26/16 is	off off off off on off on off off	A22/15	on	"...#114" E26.1 A26/12 on E26.2 A26/11 off	
Y 26.2 on Template up	"...#117" Template change/over for transfer on Aux puller up Opposite solenoid Y 26.1 de-energized if X and Y carriage movement in home position	E28.2 E41.1	A26/17 A26/16 A27/2 A22/15 is	on off on off	A22/14	on	"...#116" E26.1 A26/12 off E26.2 A26/11 on	

LOCK LIST FOR 3568-12/22

LOCK LIST FOR 3568-12/22

Function	Position of machine	Input	Card	LED Wire #	Output	LED	Feedback	LED
Y 29.2 on Folder back	"...#129" Folding unit up Opposite solenoid Y 29.1 de-energized if	E23.1	A26/8 A22/20 is	on off	A22/24	on	"...#128" E29.1 A27/23 off E29.2 A27/24 on	
Y 31 on Pocket plate on	"...#130" Folding unit up (IF) Template change/over for sewing is on (OTHERWISE CHECK) Template transfer forward	E23.1 E28.1 E28.3 E28.5 E27.1	A26/8 A26/15 A26/24 A26/3 A26/14	on on off off off	A22/22	on		
Y 40 on Vacuum stacker roller on					A23/1	on		
Y 40 off Vacuum stacker roller off					A23/1	off		
Y 41 on Puller off	"...#132" Template transfer not at forward position	E27.1	A26/14	on	A23/2	on	"...#131" E41.1 A27/2 off E41.2 A27.1 on	
Y 41 off Puller on					A23/2	off	"...#133" E41.1 A27/2 on E41.2 A27/1 off	
Y 42 on Stacker forward					A23/3	on	"...#134" E 42 A27/3 on	
Y 42 off Stacker back					A23/3	off	"...#135" E 42 A27/3 off	
Y 43 on Compressed air stacker on					A23/4	on		
Y 43 off Compressed air stacker off					A23/4	off		
K 44 on Stacker roller on					A23/5	on		
K 44 off Stacker roller off					A23/5	off		
Y 45 on Compressed air material feed aid on					A22/23	on		
Y 45 off Compressed air material feed aid off					A22/23	off		
Y 50.1 on Head off	"...#137" Carriage in home position Opposite solenoid Y 50.2 de-energized if		A23/7	is off			"...#136"	

LOCK LIST FOR 3568-12/22

Function	Position of machine	Input Card Wire #	LED	Output LED	Feedback LED
Y 50.2 on Head on	"...#139" Sew in home position Template transfer back Template change/over for transfer Opposite solenoid Y 50.1 de-energized if	E27.2 A26/13 off E28.2 A26/17 on E28.4 A26/16 off A23/6 is off	A23/7 on	"...#138" E50.1 A27/4 off E50.2 A27/6 on	
H 103 on Manual lamp on			A23/17 on		
H 103 off Manual lamp off			A23/17 off		
H 104 on Automatic lamp on			A23/18 on		
H 104 off Automatic lamp off			A23/18 off		
H 106 on Fix error lamp on			A23/20 on		
H106 off Fix error lamp off			A23/20 off		
H 114 on Lamp program A on			A22/17 on		
H 114 off Lamp program A off			A22/17 off		
H 115 on Lamp program B on			A22/16 on		
H 115 Lamp program B off			A22/16 off		
H 120 on Lamp labeling on			A22/13 on		
H 120 off Lamp labeling off			A22/13 off		
REF on Reference output for NIF on			A23/13 on		
REF off Reference output for NIF on			A23/13 off		
BOBRES on Reset for bobbin thread monitor on			A23/14 on		
BOBRES off Reset for bobbin- thread monitor off			A23/14 off		
SPWOUT on Bobbin change on			A23/8 on		
SPWOUT OFF Bobbin change off			A23/8 off		
OUT 1 on Program output 1 on			A23/9 on		
OUT 1 off Program output 1 off			A23/9 off		

LOCK LIST FOR 3568-12/22

Function	Position of machine	Input Card Wire #	LED	Output LED	Feedback LED
OUT 2 on Program output 2 on			A23/10	on	
OUT 2 off Program output 2 off			A23/10	off	

INPUT PIN BOARD		A28	INPUT PIN BOARD	A27	INPUT PIN BOARD	A26	INTERFACE PIN BOARD	A25	OUTPUT PIN BOARD	A24	OUTPUT PIN BOARD	A23	OUTPUT PIN BOARD	A22	INPUT PIN BOARD	A21
24	JIGCTR	24	E29.2	24	E28.3	24		24	S2	24	Y29.2	24				
23	ETERR	23	E29.1	23	E108B	23		23	S1	23	Y45	23				
22	ETINKL	22	SMOKPR	22	E108A	22		22	STL	22	Y31	22				
21	ETRDY	21	E103	21	E107	21		21	STR	21	Y5	21				
20	E120	20	E9	20	E31.1	20		20	H106	20	Y29.1	20				
19	ET	19	E102	19	E31.2	19		19		19	Y28.2	19				
18	ET13	18	E113	18	E37	18		18	H104	18	Y28.1	18				
17	BOBERR	17	E101	17	E28.2	17		17	H103	17	H114	17				
16		16	SPGTST	16	E28.4	16		16	B0BRES	16	H115	16				
15		15	E115	15	E28.1	15		15	REF	15	Y26.1	15				
14		14	E99	14	E27.1	14		14	Y11	14	Y26.2	14				
13		13	E98	13	E27.2	13		13	Y10	13	H120	13				
12		12	E112	12	E26.1	12		12	DUT2	12	Y24.1	12				
11		11	E111	11	E26.2	11		11	DUT1	11	Y23.1	10				
10		10	E106	10	DPTINP	10		10		9	Y23.2	9				
9		9	E104	9	KIPP	9		9								
8	JIGCODE	8	BIT7	8	E23.1	8		8	SPVOUT	8	K22	8				
7	JIGCODE	7	BIT6	7	E23.2	7		7	Y50.2	7	ETSTART	7				
6	JIGCODE	6	BIT5	6	E114	6		6	Y50.1	6	Y70	6				
5	JIGCODE	5	BIT4	5	E20.1	5		5	K44	5	Y20.1	5				
4	JIGCODE	4	BIT3	4	E20.2	4		4	Y43	4	Y20.2	4				
3	JIGCODE	3	BIT2	3	E28.5	3		3	Y42	3	Y3	3				
2	JIGCODE	2	BIT1	2	IN	2		2	Y41	2	K2	2				
1	JIGCODE	1	BIT0	1	E41.2	1		1	Y40	1	Y1	1				

4				1994	Datum	Name										Icp 3568-1/22
3				Gezeichnet	31.01		Ersetzt hier									PFAFF
2				Gepr./Gemech.	31.01		Ersetzt durch									
1				Normgepr.			Aufst. lt. Aend.-Nr.									
0	Angefertigt			Bemerkung												
Nr.	Art der Änderung			Änderung Nr.			Zeichnungs-Nr.									
				Datum			91-191 317-95									
				Blatt			Blattzahl									


Für diese Zeichnung behalten wir uns alle Rechte vor (gem. DIN 340 CAD)

Overview of the switches / proximity switches

To simplify the search for the individual transmitters (switches etc.) the layout can be seen in the following diagram.

Solid lines -> mean that the transmitter is above the table top and broken lines —> mean that the transmitter is under the table top.



Transmitter	Number in the diagram	Transmitter	Number in the diagram
B31.1	18	S1	6
B31.2		S107	11
B27.1		S9	9
B27.2		S20.1	3
		S20.2	
B28.3	17	S23.1	13
B28.4		S23.2	
B28.5		S26.1	14
		S26.2	
Position transmitter	2	S28.1	5
		S28.2	
B51.1	4	S37	12
B51.3		S29.1	10
B52.1		S29.2	
		S42	16
		S50.1	7
		S50.2	
		S98	15
		S99	1
		S108A	8
		S108B	



Monitoring the jigs / - code

The machine carries with it the option of installing a jig monitor. Here the sewing jig is marked with a magnetic code number which can be read by an additional device. The jig code must be programmed in the sewing program if it is required. If the jig monitor is on (c.f. switch functions) and the jig code does not coincide with that of the sewing program, the sewing operation will be stopped and the corresponding error message will be displayed.

The jig code has a value from 0 - 99. The order of the magnets appears in brackets in binary code behind the corresponding value. The last four figures represent the unit's place and the front four figures represent the tens.



compound table:

Value (unit's place)	Bit3 (Bit7)	Bit2 (Bit6)	Bit1 (Bit5)	Bit0 (Bit4)
0	-	-	-	-
1	-	-	-	*
2	-	-	*	-
3	-	-	*	*
4	-	*	-	-
5	-	*	-	*
6	-	*	*	-
7	-	*	*	*
8	*	-	-	-
9	*	-	-	*


(The same table also applies for the tens with Bits 4 - 7)

Example of a template code

jig code = 25.

Display of the magnet position at the input of the jig code:


— = no magnet in the jig
* = magnet in the jig



Order of the magnets on the sewing jig:

o = do not adhere magnet
* = adhere magnet

(the diagram shows the magnets as seen through the sewing jig. i.e. the magnets are on the underside of the jig).



8 Important settings

8.1 Initial loading values after cold start:

piece counter	0
bobbin preselect	10000 stitches
time for feed roller	200 ms
maximum speed	4100 RPM
reduced speed	4100 RPM
zigzag delay on	0 stitches
delay zigzag-off	0 stitches
pause off	off
puller	off
uni - material	off
end stitches for thread monitor	5 stitches
end stitches for bobbin monitor	5 stitches
monitoring stitches for thread monitor	5 stitches
automatic stitch	10 stitches
slow start stitches	2 stitches
carriage start (NIF)	90°
thread monitor	on
bobbin monitor	on
bobbin sensor	off
language	German
compressed air needle cooling feed forward	off
compressed air needle cooling stacker	off
material-feed aid feed-forward	off
material-feed aid stacker	off
material-feed aid sewing	off
thread puller	on
if tip-head installed	
- bobbin change from top	on
- otherwise	
- bobbin change from top	off
if jig monitor installed	
- jig monitor	on
- otherwise	
- jig monitor	off
labelling	off
alternate labelling	off
carriage movement(cont)	off (doesn't change at cold start)
slow insert	off (doesn't change at cold start)
Basic frontposition pocket-plate	on
time for stacker airblast	300 ms
time for folder	1 s
time for puller	400 ms
time after table up	250 ms
time for edge folders back	250 ms
time for feed forward	200 ms
time for thread puller	500 ms

8.2 Synchronizer home setting

If the synchronizer is replaced, the home value must be reset. To do this perform or check as necessary the following points in the order given.

1. **Important!**
the needle must be able to rotate freely when the machine is switched on. Check and adjust if necessary.
The synchronizer screws must be tight to avoid an uncontrolled racing of the motor.
2. Turn machine on (the needle positions itself automatically).
3. Now check if the needle has in fact positioned itself in t.d.c.
if so - ready.
if not - loosen synchronizer screws and hold the synchronizer in position. Turn hand wheel until the needle is in the desired position. Retighten synchronizer screws.
4. Now a new positioning can be carried out by turning the machine off and then on again or by selecting the service function sewing-motor and completing one rotation. Then repeat points 3 and 4 until the needle reaches the desired position.

8.3 Feed speeds

The feed speed from the folding station to the sewing station can be influenced via the potentiometer on the frequency converter.

The feed speed from the sewing station to the folding station cannot be changed.

Circuit diagrams

91-191 317-95	STP 3568 * /22 terminal connections
91-291 310-95	Adhesive foil - placements
91-191 333-95	modular mimic display
91-191 327-95 BI.1	STP power supply 220V/24V
91-191 327-95 BI.2	STP power supply 220V/24V
91-191 328-95	STP 3568 * /22 (A22)
91-191 329-95	STP 3568 * /22 (A23)
91-191 330-95	STP 3568 * /22 (A26)
91-191 331-95	STP 3568 * /22 (A27)
91-191 312-95	STP 3568 * /22 (A28)
91-291 295-71/893 BI.1	Control-panel folding station
91-291 295-71/893 BI.2	Control-panel folding station
91-191 325-95	Connection-plan control panel of control unit
91-191 326-95	STP frequency converter
91-191 340-95	STP sewing drive
91-191 344-95	STP stepping motor
91-191 319-95	STP connection serial interface

INPUT PIN BOARD		A28	INPUT PIN BOARD	A27	INPUT PIN BOARD	A26	INTERFACE PIN BOARD	A25	OUTPUT PIN BOARD	A24	OUTPUT PIN BOARD	A23	OUTPUT PIN BOARD	A22	INPUT PIN BOARD	A21
24	JIGCTR	24	E29.2	24	E28.3	24		24	S2	24	Y29.2	24				
23	ETERR	23	E29.1	23	E108B	23		23	S1	23	Y45	23				
22	ETINKL	22	SMOKPR	22	E108A	22		22	STL	22	Y31	22				
21	ETRDY	21	E103	21	E107	21		21	STR	21	Y5	21				
20	E120	20	E9	20	E31.1	20		20	H106	20	Y29.1	20				
19	ET	19	E102	19	E31.2	19		19		19	Y28.2	19				
18	ET13	18	E113	18	E37	18		18	H104	18	Y28.1	18				
17	BOBERR	17	E101	17	E28.2	17		17	H103	17	H114	17				
16		16	SPGTST	16	E28.4	16		16	B0BRES	16	H115	16				
15		15	E115	15	E28.1	15		15	REF	15	Y26.1	15				
14		14	E99	14	E27.1	14		14	Y11	14	Y26.2	14				
13		13	E98	13	E27.2	13		13	Y10	13	H120	13				
12		12	E112	12	E26.1	12		12	DUT2	12	Y24.1	12				
11		11	E111	11	E26.2	11		11	DUT1	11	Y23.1	10				
10		10	E106	10	DPTINP	10		10		9	Y23.2	9				
9		9	E104	9	KIPP	9		9								
8	JIGCODE	8	BIT7	8	E23.1	8		8	SPVOUT	8	K22	8				
7	JIGCODE	7	BIT6	7	E23.2	7		7		7	ETSTART	7				
6	JIGCODE	6	BIT5	6	E114	6		6		6	Y70	6				
5	JIGCODE	5	BIT4	5	E20.1	5		5		5	Y20.1	5				
4	JIGCODE	4	BIT3	4	E20.2	4		4		4	Y20.2	4				
3	JIGCODE	3	BIT2	3	E28.5	3		3		3	Y3	3				
2	JIGCODE	2	BIT1	2	IN	2		2		2	K2	2				
1	JIGCODE	1	BIT0	1	E41.2	1		1		1	Y1	1				


4				1994	Datum	Name										Isp 3568-1/22
3				Gezeichnet	31.01		Ersetzt hier									
2				Gepr./Gemech.	31.01		Ersetzt durch									
1				Normgepr.			Ausf. lt. Aend.-Nr.									
0	Angefertigt			Bemerkung												
Nr.	Art der Änderung															

PFAFF


Zeichnungs-Nr. 91-191 317-95
Blattzahl Blatt

STP 3568-1/22

Für diese Zeichnung behalten wir uns alle Rechte vor (Gem DIN 340 CAD)



95-745 561-75



9

dazu: Anschlußplan Bedienfeld Steuergerät
91-291 325-91
dazu: 0,1 Blatt Schild (Bedienpunkt)
71-0100-0091

卷之三

PEACE

100

durch:


And.-Nr.

ungs-Nr.


E68/V,-567:160


Blatt: 1


100





* 4x Optokoppler
siehe Blatt 2
oder 91-191 326-95



















A1	Netzgerät	M-NG-5A	91-290	435-91
A3	Best.Ltp.	M-ZE-9/009	91-290	587-93/009
A4	Best.Ltp.	M-MR-3/001	91-290	060-93/001
A5	Best.Ltp.	M-SM-3/018	91-093	459-93/018
A6	Best.Ltp.	M-EA-2/004	91-092	767-93/004
A7	Best.Ltp.	M-EA-2/006	91-092	767-93/006
A8	Best.Ltp.	M-EA-2/005	91-092	767-93/005
A20	Best.Ltp.	M-NG-2	91-093	329-91
A22	Best.Ltp.	M-0A-1	91-092	323-91
A23	Best.Ltp.	M-0A-1	91-092	323-91
A26	Best.Ltp.	M-0E-1	91-092	321-91
A27	Best.Ltp.	M-0E-1	91-092	321-91
A28	Best.Ltp.	M-0E-1	91-092	321-91
A80	Motorenstufe	10A	91-290	343-91


Schrift schwarz, Hintergrund transparent.

ähnlich 91 093 854-9		4 3 2 1 0	Eingef. lt.						9
Paßmaß	Abmaße	Nr.	Zahl kommt vor	Änderung Nr.	Datum	Bearb.	Oberflächenzustand	Schl.- zahl x	
Allgemeintoleranzen:				Tolerierung DIN ISO 8015			Typ:	3568-2/22	
1994	Datum	Name	Oberflächen DIN ISO 1302	Werkstoff: Klebefolie (transparent)			PFAFF		
Gezeichnet	04.02.			Werkstückkanten:			Ersatz für:		
Geprüft	04.02.				Hergestellt aus:		Ersetzt durch:		
Fkt. gepr.							Ausf. lt. Änd.-Nr.		
Normgepr.									
Genehmigt									
Maßstab				Benennung:			Zeichnungs-Nr.		
1:1				Klebefolie (Nummerierung)			91-291 309-X5		
Schutzvermerke nach DIN 34 beachten. Copyright reserved.							CAD	Blattzahl:	Blatt:






91-291 300-91




91-291 357-73/001 is new number for the Lust unit

PU 1202
41-7500-0209



Optocoupler part # 71-6400-0346




3568-12/22

上
卷

STP Frequency Converter

91-191 326-95


Page of



Allgemeintoleranzen:						Tolerierung DIN ISO 8015	Typ: 3566 - x / 12		
Paßmaß	Abmaß	Nr. Kennr. ver	Einheit	Zahl	Änderung Nr.	Datum	Bearb.	Oberflächenzustand	Schraubenanz.
				0	Eingef. 11.	1-36 516			
				1					
				2					
				3					
				4					

PFAFF


Motoranschlußkästen





(11-173 171-25 (4x))
(12-305 114-25 (4x))
(11-724 300-55 (4x))
(12-024 151-25 (4x))
(71-3700-0217 (6x))
(71-3700-0353 (3x))
71-3100-0006 (5x)
71-3100-0008 (4x)
71-3100-0009 (3x)
71-3100-0010
71-0100-0141


Dazu STP 91-151 346-95

Schutzvermerke nach DIN 34 beachten. Copyright reserved CAD Blattzahl: Blatt:
Zeichnungs-Nr.: 91-291 373-95
Auff. lt. 7nd.-Nr. 1-36 921
Ersatz durch:
Zeichnungs-Nr.:
Montageplatte Frequenzumrichter
Benennung:
Maßstab: -










Wiring connections for the interface cable
used on the Pfaff System 3000 program unit

1.4.2 Steuerkarte D 650.0X

1.4.2.1 Betriebsdaten

Betriebsspannung	70 - 130 VDC ± 10%
Phasenströme einstellbar	2,0 - 5,0 A
Boost einstellbar	1,0 - 1,9xI _N (max.6A)
Anzeige für Bereitschafts- und Störungsanzeigen	LEDs
Drehschalter zur Einstellung des Boost	
Drehschalter zur Einstellung des Phasenstroms	

1.4.2.2 Anzeige und Programmierschalter



If the machine has four dip switch

1.4.2.3 Boost (Grenzwert $I_{Boost} = 6 \text{ A max.}$)

I_{Boost}	$1,0 \times I_N$	$1,1 \times I_N$	$1,2 \times I_N$	$1,3 \times I_N$	$1,4 \times I_N$	$1,5 \times I_N$	$1,6 \times I_N$	$1,7 \times I_N$	$1,8 \times I_N$	$1,9 \times I_N$
Stellung	0	1	2	3	4	5	6	7	8	9

top rotary dial switch must point to the O position

1.4.3.3 Phasenstrom (Angabe in A)

$I(A)$	2,0	2,2	2,4	2,6	2,8	3,0	3,2	3,4	3,6	3,8
Stellung	0	1	2	3	4	5	6	7	8	9

$I(A)$	4,0	4,2	4,4	4,6	4,8	5,0				
Stellung	A	B	C	D	E	F				

bottom rotary dial switch must point to the F position

1.4.3.4 Stromabsenkung

Schalterstellung	OFF		ON	
Pulsfrequenz	<10 Hz	>10 Hz	<10 Hz	>10 Hz
Motorstrom I	$I_{Nenn} \times 0,6$	I_{Nenn}	I_{Nenn}	I_{Nenn}

1.4.3.5 Schrittwinkel

Schalterstellung	OFF	ON
Schrittwinkel	Halbschritt 1000 Schritte pro Umdrehung	Vollschrift 500 Schritte pro Umdrehung

switch # 3

Half step

Full step