SINGER PARTS CHART FOR SINGER MODEL 132B6 · 132B7



* For 132 B6 only

PARTS CHART FOR SINGER MODEL 132B6 · 132B7



FORM IPD 682-7
PRINTED IN JA